

# ***TECHNO TOY TUNING***

## ***AE86 TRACTION BRACKETS***

### ***PACKING/HARDWARE LIST:***

- 1) Pair of traction Brackets. (Left and right)
- 2) Long 12mm spacer
- 2) Short 12mm spacer
- 6) 12-1.25x90 hex head bolts with nylock nuts
- 20) ½ inch flat washers

(Traction brackets will come with hardware already on Traction Brackets)

Once you have removed the 4 links from the axle side you are ready to install your new traction brackets.



Slide the traction bracket over bare bracket with the hump on the same side as the shock tab.



Once the traction bracket is slid into place install the large and small tubes through the flange and traction bracket.



Install the 12-1.25x90 bolts through the 12mm spacers and bolt them down.

Final torque to 65ft/lbs.



Once you have the traction bracket torqued into place all that is left is putting the links back onto either one of the two holes on the end of the traction bracket.

Photo of completed side shown below



Once you have one side completed move to the next side and repeat the process. (Once all bolted up make sure pinion angle is as close to factory as possible)

***WE HOPE YOU ENJOY THE  
PERFORMANCE AND AESTHETICS  
OF YOUR NEW TECHNO TOY TUNING  
TRACTION BRACKETS.***

***ANY QUESTIONS PLEASE E-MAIL  
US AT***

***[INFO@TECHNOTOYTUNING.COM](mailto:info@technotoytuning.com)***