

# ***TECHNO TOY TUNING***

## ***AE86 LATERAL ROD DROP MOUNTS***

### ***PACKING LIST:***

- 1) Pair of lateral rod drop mounts.
- 1) hardware kit.

### ***HARDWARE KIT CONTENTS:***

- 1) Datsun nut (12-1.25 thread pitch).
- 1) 20-2.5X75 bolt and nylock.
- 1) 20mm spacer.
- 1) 10-1.25x25 bolt.
- 1) 10mm spacer.
- 1) 12-1.25x70 bolt with nylock.
- 2) 12mm milspec washers.
- 1) 12mm spacer.

Once you have completely removed the lateral rod, you are ready to begin the install your lateral rod drop mounts. (Photo of bare axle side shown below)



Start by installing the side of the drop mount with the two larger holes.



Should look like this.

(May have to tap into place with mallet if one or both pins are slightly bent)



Install shock on the shock tab and install 10mm spacer into shock bushing and install 20mm spacer onto lateral rod pin as shown above.



Install second half of drop mount with the 10mm bolt hole on the shock side. Install 10-1.25x25 bolt, Datsun and 12-1.25x70 bolt as shown above.

(10-1.25x25 bolt Torque to 35ft/lbs)

(Datsun nut torque to 22ft/lbs)

(12-1.25x70 bolt torque to 65ft/lbs)



Select one of the three holes that puts lateral rod closest to factory angle.



Should look like this once completed.

Once everything is tightened up make sure axle is centered.

***WE HOPE YOU ENJOY THE  
PERFORMANCE AND AESTHETICS OF  
YOUR NEW TECHNO TOY TUNING  
LATERAL ROD DROP MOUNTS.***

***ANY QUESTIONS PLEASE E-MAIL US AT  
INFO@TECHNOTOYTUNING.COM***