

***TECHNO TOY TUNING***  
***ZZW30 MICRO BRAKE KIT***  
***INSTALLATION INSTRUCTIONS***

***PACKING LIST:***

- 2) Wilwood Calipers
- 2) caliper Brackets
- 2) Rotor Alignment Rings
- 2) Brake Rotors
- 2) Stainless Brake Lines
- 1) Box Wilwood Brake Pads

***HARDWARE KIT CONTENTS:***

- Qty 2) 90-Degree brake line elbows
- Qty 4) 12-1.25x30mm Bolts w/ Lock washers
- Qty 4) 3/8-24x1<sup>3</sup>/<sub>4</sub> Socket Head Bolts w/ Milspec flat washers
- Qty 2) L Brackets for to hold stainless lines



Once you have completely removed your factory brakes and have your bare hubs, you will be ready to proceed.

(Photo Shown above)





Install the as shown using the two 12-1.25x30mm bolts and lock washers. Torque to 60ft/lbs.



Install the rotor alignment ring as shown.



Install the rotor onto the hub assembly. Snug the lugs up by hand to hold the rotor in place.



Slide the caliper over the rotor and align bolt holes on the bracket. Install the two 3/8-24x1<sup>3</sup>/<sub>4</sub> allen head bolts and milspec washers.

Torque to 30ft/lbs.

Remove the caliper retainer from the caliper, install the pads and re-install the retainer. Install elbow fittings into the caliper (2-3 turns past hand tight), install the brake lines and orient correctly so they do not rub or get pinched. Repeat the procedure on opposite side and bleed brakes. Clean well and check for firm pedal and no leaks. Install the wheels and you are ready to go!!!

***WE HOPE YOU ENJOY THE  
PERFORMANCE AND AESTHETICS  
OF YOUR NEW TECHNO TOY TUNING  
BRAKE KIT!***

***ANY QUESTIONS PLEASE E-MAIL  
US AT***

***[INFO@TECHNOTOYTUNING.COM](mailto:INFO@TECHNOTOYTUNING.COM)***